I'm not robot
reCAPTCHA
Continue

Electric club car rear differential oil change

sent by Bruno | 9 October 2009 | In Golf Cart Repair | Club Carrelli Golf Carts need the rear axle/back oil changed periodically. That's how you do it. 1: Take your golf cart out for a rotation for about 15 minutes to heat oil for faster discharge. 2: Park your golf cart on a level surface. Put a pan of oil under the cart. Ether use a 14mm socket or a key to remove the rear exhaust plug (see photo.) You can use a jack on the opposite side to tilt the back enough to make sure you get all the drained oil. If you have a pump with tube, you can get even more oil out. 3: After draining the oil, replace the drain plug and remove the filling plug. You can use an oil pump to fill it back if you have one. If not you can use a funnel and a small pipe. Your pipe should fit in the hole in the hole so that the air moves around it during filling. You can remove the panel behind the seat and release the oil pipe down to fill the back with oil. The manual requires SAE 30w oil. You can use a heavier weight gear oil for greater protection, but the manufacturer says 30w the way to go. 4: Fill the back with oil until it begins to exit the hole. When you reach that point, you're full. 5: Reinstall the filling plug and clean any oil that leaked around the back. Got it. > > >